

gEDA /gaf File Format Document

Alex V. Hvezda, ahvezda@geda.seu.lorg

This document is released under GFDL
(<http://www.gnu.org/copyleft/fdl.html>)

November 30th, 2002

Contents

1	Overview	3
2	Coordinate Space	3
3	Filenames	4
4	Object types	4
4.1	version	4
4.2	line	5
4.3	box	6
4.4	circle	8
4.5	arc	9
4.6	text	10
4.7	net	12
4.8	bus	12
4.9	pin	13
4.10	component	14
4.11	font	14
5	Colors	15
6	Attributes	15
7	Embedded Components	16
8	Document Revision History	17

1 Overview


This file is the official documentation for the file formats in gEDA /gaf (G Schematic And Friends). The primary file format used in gEDA /gaf is the schematic/symbol format. Files which end with `.sch` or `.sym` are schematics or symbol files. Until there is another file type in gEDA /gaf, then this document will only cover the symbol/schematic file format.

This file format document is current as of gEDA /gaf version 20021103.

2 Coordinate Space

- All coordinates are in mils (1/1000 of an inch). This is an arbitrary decision. Remember in there is no concept of physical lengths/dimensions in schematics and symbols (for schematic capture only).
- Origin is in lower left hand corner.
- The size of the coordinate space is unlimited, but it is recommended that all objects stay within (120.0, 90.0) (x, y inches).
- It is generally advisable to have positive x and y coordinates, however, negative coordinates work too, but not recommended.

The following figure shows how the coordinate space is setup:



X axis increases going to the right. Y axis increase going up. Coordinate system is landscape and corresponds to a sheet of paper turned on its side.

3 Filenames

Symbols end in `.sym`. The only symbol filename convention that is used in gEDA/gaf is that if there are multiple instances of a symbol with the same name (like a 7400), then a -1, -2, -3, ... -N suffix is added to the end of the filename. Example: 7400-1.sym, 7400-2.sym, 7400-3.sym ...

Schematics end in `.sch`. There used to be a schematic filename convention (adding a -1 .. -N to the end of the basename), but this convention is now obsolete. Schematic filenames can be anything that makes sense to the creator.

4 Object types

A schematic/symbol file for gEDA/gaf consists of:

- A version (v) as the first item in the file. This is required.
- Any number of objects and the correct data. Objects are specified by an "object type"
- Most objects are a single line, however text objects are two lines long.
- No blank lines at the end of the file (these are ignored by the tools)
- For all enumerated types in the gEDA/gaf file formats, the field takes on the numeric value.

The "object type" id is a single letter and this id must start in the first column. The object type id is case sensitive.

The schematic and symbol files share the same file layout. A symbol is nothing more than a collection of primitive objects (lines, boxes, circles, arcs, text, and pins). A schematic is a collection of symbols (components), nets, and buses.

The following sections describe the specifics of each recognized object type. Each section has the name of the object, which file type (sch/sym) the object can appear in, the format of the data, a description of each individual field, details and caveats of the fields, and finally an example with description.

For information on the color index (which is used in practically all objects), see the Color section.

4.1 version

Valid in: Schematic and Symbol files

type version

Field	Type/unit	Description
type	char	v
version	int	version of gEDA /gaf file

- The type is a lower case "v" (as in Victor).
- This object must be in every file used or created by the gEDA /gaf tools.
- The format of the version is YYYYMMDD.
- The version number is not an arbitrary timestamp. Do not make up a version number and expect the tools to behave properly.
- The version number is used to keep track of file format variations.

Valid versions include:

19990601,19990610,19990705,19990829,19990919,19991011,20000220,20000704,
20001006,20001217,20010304,20010708,20010722,20020209,20020414,20020527,
20020825,20021103,20030223,20030525,20030901

Keep in mind that each of the listed versions might have had file format variations. This document only covers the last version's file format.

Example:

v 20021103

4.2 line

Valid in: Schematic and Symbol files

type x1 y1 x2 y2 color width capstyle dashstyle dashlength dashspace

Field	Type/unit	Description
type	char	L
x1	int/mils	First X coordinate
y1	int/mils	First Y coordinate
x2	int/mils	Second X coordinate
y2	int/mils	Second Y coordinate
color	int	Color index
width	int/mils	Width of line
capstyle	int	Line cap style
dashstyle	int	Type of dash style
dashlength	int	Length of dash
dashspace	int	Space inbetween dashes

- The capstyle is an enumerated type:

- END_NONE = 0
- END_SQUARE = 1
- END_ROUND = 2

- The dashstyle is an enumerated type:

- TYPE_SOLID = 0
- TYPE_DOTTED = 1
- TYPE_DASHED = 2
- TYPE_CENTER = 3
- TYPE_PHANTOM = 4

- The dashlength parameter is not used for TYPE_SOLID and TYPE_DOTTED. This parameter should take on a value of -1 in these cases.
- The dashspace parameter is not used for TYPE_SOLID. This parameter should take on a value of -1 in these case.

Example:

L 23000 69000 28000 69000 3 40 0 1 -1 75

A line segment from (23000, 69000) to (28000, 69000) with color index 3, 40 mils thick, no cap, dotted line style, and with a spacing of 75 mils in between each dot.

4.3 box

Valid in: Schematic and Symbol files

type x y width height color width capstyle dashtype dashlength dashspace
filltype fillwidth angle1 pitch1 angle2 pitch2

- The capstyle is an enumerated type:

- END_NONE = 0
- END_SQUARE = 1
- END_ROUND = 2

- The dashstyle is an enumerated type:

- TYPE_SOLID = 0
- TYPE_DOTTED = 1
- TYPE_DASHED = 2
- TYPE_CENTER = 3
- TYPE_PHANTOM = 4

Field	Type/unit	Description
type	char	B
x	int/m ils	Lower left hand X coordinate
y	int/m ils	Lower left hand Y coordinate
w idth	int/m ils	W idth of the box (x direction)
height	int/m ils	Height of the box (y direction)
color	int	Color index
w idth	int/m ils	W idth of lines
capstyle	int/m ils	Line cap style
dashstyle	int	Type of dash style
dashlength	int/m ils	Length of dash
dashspace	int/m ils	Space inbetween dashes
filltype	int	Type of fill
fillw idth	int/m ils	W idth of the fill lines
angle1	int/degrees	F irst angle of fill
pitch1	int/m ils	F irst pitch/spacing of fill
angle2	int/degrees	Second angle of fill
pitch2	int/m ils	Second pitch/spacing of fill

- The dashlength param eter is not used for TYPE _S O L I D and TYPE _D O T T E D . This param eter should take on a value of -1 in these cases.
- The dashspace param ater is not used for TYPE _S O L I D . This param eter should take on a value of -1 in these case.
- The filltype param eter is an enum erated type:
 - FILLING _H O L L O W = 0
 - FILLING _F I L L = 1
 - FILLING _M E S H = 2
 - FILLING _H A T C H = 3
 - FILLING _V O I D = 4 unused
- If the filltype is 0 (FILLING _H O L L O W), then all the fill param eters should take on a value of -1.
- The fill type FILLING _F I L L is a solid color fill.
- The two pairs of pitch and spacing control the fill or hatch if the fill type is FILLING _M E S H .
- Only the first pair of pitch and spacing are used if the fill type is FILLING _H A T C H .

Example:

B 33000 67300 2000 2000 3 60 0 2 75 50 0 -1 -1 -1 -1 -1

A box with the lower left hand corner at (33000,67300) and a width and height of (2000,2000), color index 3, line width of 60 mils, no cap, dashed line type, dash length of 75 mils, dash spacing of 50 mils, no fill, rest parameters unset.

4.4 circle

Valid in: Schematic and Symbolfiles

type x y radius color width capstyle dashtype dashlength dashspace
filltype fillwidth angle1 pitch1 angle2 pitch2

Field	Type/unit	Description
type	char	V
x	int/mils	Center X coordinate
y	int/mils	Center Y coordinate
radius	int/mils	Radius of the circle
color	int	Color index
width	int/mils	Width of circle line
capstyle	int/mils	0 unused
dashstyle	int	Type of dash style
dashlength	int/mils	Length of dash
dashspace	int/mils	Space inbetween dashes
filltype	int	Type of fill
fillwidth	int/mils	Width of the fill lines
angle1	int/degrees	First angle of fill
pitch1	int/mils	First pitch/spacing of fill
angle2	int/degrees	Second angle of fill
pitch2	int/mils	Second pitch/spacing of fill

- The dashstyle is an enumerated type:
 - TYPE_SOLID = 0
 - TYPE_DOTTED = 1
 - TYPE_DASHED = 2
 - TYPE_CENTER = 3
 - TYPE_PHANTOM = 4
- The dashlength parameter is not used for TYPE_SOLID and TYPE_DOTTED. This parameter should take on a value of -1 in these cases.
- The dashspace parameter is not used for TYPE_SOLID. This parameter should take on a value of -1 in these case.
- The filltype parameter is an enumerated type:

- FILLING_HOLLOW = 0
- FILLING_FILL = 1
- FILLING_MESH = 2
- FILLING_HATCH = 3
- FILLING_VOID = 4 unused

- If the filltype is 0 (FILLING_HOLLOW), then all the fill parameters should take on a value of -1.
- The fill type FILLING_FILL is a solid color fill.
- The two pairs of pitch and spacing control the fill or hatch if the fill type is FILLING_MESH .
- Only the first pair of pitch and spacing are used if the fill type is FILLING_HATCH .

Example:

```
V 38000 67000 900 3 0 0 2 75 50 2 10 20 30 90 50
```

A circle with the center at (38000, 67000) and a radius of 900 mils, color index 3, line width of 0 mils (smallest size), no cap, dashed line type, dash length of 75 mils, dash spacing of 50 mils, mesh fill, 10 mils thick mesh lines, first mesh line: 20 degrees, with a spacing of 30 mils, second mesh line: 90 degrees, with a spacing of 50 mils.

4.5 arc

Valid in: Schematic and Symbol files

type x y radius startangle sweepangle color width capstyle dashtype
dashlength dashspace

- The startangle can be negative, but not recommended.
- The sweepangle can be negative, but not recommended.
- The capstyle is an enumerated type:
 - END_NONE = 0
 - END_SQUARE = 1
 - END_ROUND = 2
- The dashstyle is an enumerated type:
 - TYPE_SOLID = 0
 - TYPE_DOTTED = 1

Field	Type/unit	Description
type	char	A
x	int/mils	Center X coordinate
y	int/mils	Center Y coordinate
radius	int/mils	Radius of the arc
startangle	int/degrees	Starting angle of the arc
sweepangle	int/degrees	Amount the arc sweeps
color	int	Color index
width	int/mils	Width of circle line
capstyle	int	Cap style
dashstyle	int	Type of dash style
dashlength	int/mils	Length of dash
dashspace	int/mils	Space inbetween dashes

- TYPE_DASHED = 2
- TYPE_CENTER = 3
- TYPE_PHANTOM = 4

- The dashlength parameter is not used for TYPE_SOLID and TYPE_DOTTED. This parameter should take on a value of -1 in these cases.
- The dashspace parameter is not used for TYPE_SOLID. This parameter should take on a value of -1 in these case.

Example:

A 30600 75000 2000 0 45 3 0 0 3 75 50

An arc with the center at (30600, 75000) and a radius of 2000 mils, a starting angle of 0, sweeping 45 degrees, color index 3, line width of 0 mils (smallest size), no cap, center line type, dash length of 75 mils, dash spacing of 50 mils.

4.6 text

Valid in: Schematic and Symbol files


type x y color size visibility show_name value angle alignment
string

- This object is a multi line object. The first line contains all the text parameters and the second line is the text string.
- The minimum size is 2 points (1/72 of an inch).
- There is no maximum size.
- The coordinate pair is the origin of the text item.

Field	Type/unit	Description
type	char	T
x	int/mils	First X coordinate
y	int/mils	First Y coordinate
color	int	Color index
size	int/points	Size of text
visibility	int	Visibility of text
show_name_value	int	Attribute visibility control
angle	int/degrees	Angle of the text
alignment	int	Alignment/origin of the text
string	string	The text string, on a separate line

- The visibility field is an enumerated type:
 - INVISIBLE = 0
 - VISIBLE = 1
- The show_name_value is an enumerated type:
 - SHOW_NAME_VALUE = 0 (show both name and value of an attribute)
 - SHOW_VALUE = 1 (show only the value of an attribute)
 - SHOW_NAME = 2 (show only the name of an attribute)
- The show_name_value field is only valid if the string is an attribute (string has to be in the form : name = value to be considered an attribute).
- The angle of the text can only take on one of the following values: 0, 90, 180, 270. A value of 270 will always generate upright text.
- The alignment/origin field controls the relative location of the origin.
- The alignment field can take a value from 0 to 8.

The following diagram shows what the values for the alignment field mean:



Example:

T 16900 35800 3 10 1 0 0 0

Text string!

A text object with the origin at (16900, 35800), color index 3, 10 points in size, visible, attribute flags not valid (not an attribute), origin at lower left, string: Text string!

4.7 net

Valid in: Schematic files ONLY

type x1 y1 x2 y2 color

Field	Type/unit	Description
type	char	N
x1	int/mils	First X coordinate
y1	int/mils	First Y coordinate
x2	int/mils	Second X coordinate
y2	int/mils	Second Y coordinate
color	int	Color index

- Nets can only appear in schematic files.
- You cannot have a zero length net (the tools will throw them away).

Example:

N 12700 29400 32900 29400 4

A net segment from (12700, 29400) to (32900, 29400) with color index 4.

4.8 bus

Valid in: Schematic files ONLY

type x1 y1 x2 y2 color ripperdir

Field	Type/unit	Description
type	char	U
x1	int/mils	First X coordinate
y1	int/mils	First Y coordinate
x2	int/mils	Second X coordinate
y2	int/mils	Second Y coordinate
color	int	Color index
ripperdir	int	Direction of bus rippers

- The ripperdir field for an brand new bus is 0.

- The `ripperdir` field takes on a value of 1 or -1 when a net is connected to the bus for the first time. This value indicates the direction of the ripper symbol. The ripper direction is set to the same value for the entire life of the bus object.
- Buses can only appear in schematic files.
- You cannot have a zero length bus (the tools will throw them away).

Example:

```
U 27300 37400 27300 35300 3 0
```

A bus segment from (27300, 37400) to (27300, 35300) with color index 3 and no nets have been connected to this bus segment..

4.9 pin

Valid in: Symbolfiles ONLY

type x1 y1 x2 y2 color ptype whichend

Field	Type/unit	Description
type	char	P
x1	int/mils	First X coordinate
y1	int/mils	First Y coordinate
x2	int/mils	Second X coordinate
y2	int/mils	Second Y coordinate
color	int	Color index
ptype	int	Type of pin
whichend	int	Specifies the active end

- The `ptype` is an enumerated type:
 - `NORMAL_PIN` = 0
 - `BUS_PIN` = 1 unused
- The `whichend` specifies which end point of the pin is the active connection port. Only this end point can have other pins or nets connected to it.
- To make the first end point active, `whichend` should be 0, else to specify the other end, `whichend` should be 1.
- Pins can only appear in symbolfiles.
- You cannot have a zero length pin (the tools will throw them away).

Example:

```
P 0 200 200 200 1 0 0
```

A pin from (0, 200) to (200, 200) with color index 1, a regular pin, and the first point being the active connection end.

4.10 component

Valid in: Schematic files ONLY

type x y selectable angle mirror basename

Field	Type/unit	Description
type	char	C
x	int/mils	Origin X coordinate
y	int/mils	Origin Y coordinate
selectable	int	Selectable flag
angle	int/degrees	Angle of the component
mirror	int	Mirror around Y axis
basename	string	The filename of the component

- The `selectable` field is either 1 for selectable or 0 if not selectable.
- The `angle` field can only take on the following values: 0, 90, 180, 270.
- The `angle` field can only be positive.
- The `mirror` flag is 0 if the component is not mirrored (around the Y axis).
- The `mirror` flag is 1 if the component is mirrored (around the Y axis).
- The `just` `basename` is the filename of the component. This filename is not the fullpath.

Example:

C 18600 19900 1 0 0 7400-1.sym

A component whos origin is at (18600,19900), is `selectable`, not rotated, not mirrored, and the `basename` of the component is 7400-1.sym .

4.11 font

Valid in: Special font files ONLY

type character width flag

Field	Type/unit	Description
type	char	F
character	char	The character being defined
width	int/mils	Width of the character (mils)
flag	int	Special space flag

- This is a special tag and should ONLY show up in font definition files.

- If the font character being defined is the space character (32) then flag should be 1, otherwise 0.

Example:

```
F _ 11 1
```

The above font definition is for the space character.

5 Colors

In the gEDA /gaf schematic and symbol file format colors are specified via an integer index. The relationship between integer and color is based on object type. Each object type typically has one or more colors. Here is a table of color index to object type:

Color Index	Object type
0	BACKGROUND_COLOR
1	PIN_COLOR
2	NET_ENDPOINT_COLOR
3	GRAPHIC_COLOR
4	NET_COLOR
5	ATTRIBUTE_COLOR
6	LOGIC_BUBBLE_COLOR
7	GRID_COLOR
8	DETACHED_ATTRIBUTE_COLOR
9	TEXT_COLOR
10	BUS_COLOR
11	SELECT_COLOR
12	BOUNDINGBOX_COLOR
13	ZOOM_BOX_COLOR
14	STROKE_COLOR
15	LOCK_COLOR
16	OUTPUT_BACKGROUND_COLOR

The actual color associated with the color index is defined on a per toolbases. Objects are typically assigned their corresponding color index, but it is permissible (sometimes) to assign other color index values to different object types.

6 Attributes

Attributes are enclosed in { } and can only be text. Attributes are text items which take on the form name= value. If it doesn't have name= value, it's not an attribute. Attributes are attached to the previous object. Here's an example:

```

P 988 500 1300 500 1
{
T 1000 570 5 8 1 1 0
pinseq=3
T 1000 550 5 8 1 1 0
pinnumber=3
}

```

The object is a pin which has an attribute pinnumber= 3 and pinseq= 3 (name= value). You can have multiple text objects (both the T ... and text string are required) in between the { }. As of 20021103, you can only attached text items as attributes. Attaching other object types as attributes is unsupported.

You can also have "toplevel" attributes. These attributes are not attached to any object, but instead are just text objects that take on the form name= value. These attributes are useful when you need to convey some info about a schematic page or symbol and need the netlister to have access to this info.

7 Embedded Components

Embedded components are components which have all of their definition stored within the schematic file. When a user places a component onto a schematic page, they have the option of making the component embedded. Other than storing all the symbol information inside of the schematic, an embedded component is just any other component. Embedded components are defined as:

```

C 18600 21500 1 0 0 EMBEDDED555-1.sym
[
...
... Embedded primitive objects
...
]

```

In the example above, 555-1.sym is the component. The EMBEDDED tag and the [] are the distinguishing characteristics of embedded components. componentname.sym must exist in one of the specified component-libraries if you want to unembed the component.

8 Document Revision History

November 30th, 2002	Created fileform ats.tex from fileform ats.html.
December 1st, 2002	Continued work on this document.